



using one of these routes.

• Using railings around the dangerous area.

• Through personal fall arrest systems for people.

At what height is fall protection required?
OSHA states that employers must provide fall protection on jobsites where workers are exposed to falls of more than 6 feet .

Thus, before beginning work on the site, the employer must secure the site and the workers

• Installing protection or safety nets systems. At Visornets, we have a extensive catalog of

safety and protective nets. In this regard, the sales team of Visor Fall Arrest Nets can advise






you on the best system for your case. You can contact us at international@visornets.com.

One or the other options should be used depending on the location of the job.









Extending safety nets outward from the outermost projection of the work surface

Vertical distance from working level to horizontal plane of net	Minimum required horizontal distance of outer edge of net from the edge of the working surface
Up to 5 feet	8 feet
5 to 10 feet	10 feet
More than 10 feet	13 feet



Source: OSHA








What does the drop test consist of?
OSHA requirements for falls protection determine that the test involves the precipitation of a 400-pound bag of sand. The bag should be between 28 and 32 inches in diameter.
The mass should be thrown into the safety net from the level where workers are exposed to the risk. This distance should not be less than 42 inches.











What requirements must safety nets meet according to OSHA?
As per OSHA, the maximum mesh size should not exceed 6 inches by 6 inches. In addition,
each safety net must be lined with rope with a minimum breaking strength of 5,000 pounds.
For more information about the OSHA requirements for falls protection, you can visit the Occupational Safety and Health Adminsitration's web.